

# HORNFELS

1.8m

5' 11"

---

250V ~ 50Hz 10A

---



AA-2545910-2

Made in China

© Inter IKEA Systems B.V. 2024

---

IKEA of Sweden AB  
SE-343 81 Älmhult

---



Design and Quality  
IKEA of Sweden

1R15-IDG DM

中文	3
English	5
繁中	7

# 中文



请仔细阅读此说明手册，并妥善保管，以便日后参考。

## 重要须知！

- 请勿按顺序依次连接。
- 使用时请勿遮盖产品。
- 断开电源时，请拔下插头。
- 仅可在室内干燥区域使用。

## 警告

- 产品损坏后请丢弃。
- 由于温度负载升高，因此只有当线缆展开时才能使用。
- 超负荷使用产品。
- 切勿浸入水中或其他液体中。
- 使用不当可能会损坏产品，或造成人员伤害或财产损失。
- 请勿让儿童玩耍设备。

## 保养说明

清洁产品时，请拔下电源插头，并用干布擦拭。

## 产品须知

不使用时，请从电源上拔下加长电线。

## 技术数据

型号：HORNFELS 斯库塔

类型：E2309-CN

250V ~ 50Hz 10A 最大2500W



带十字的垃圾桶标志代表该产品必须与家用垃圾分开处理。同时对产品的处理必须符合当地关于废物处理的相关规定。每做一次分类，就减少了送入焚烧炉和垃圾填埋场垃圾的数量，进而将不利于人类身体健康和环境的负面影响最小化。想了解更多，请联系当地宜家商场。

# English



**Read instructions carefully and keep for future reference.**

## **IMPORTANT!**

- Do not connect after each other in a sequence.
- Do not cover the product when in use.
- To disconnect the power, pull the plug.
- Use only indoors in dry areas.

## **WARNING**

- Discard the product if damaged.
- Only operate when uncoiled due to increased temperature load.
- Do not overload the product.
- Never submerge in water or other liquids.
- Improper use may cause damage to the product or endanger people or property.
- Children should be supervised to ensure they do not play with the product.

## Care instructions

To clean the product, unplug from power source and wipe with a dry cloth.

## Good to know

Unplug the extension cord from the power source when not in use.

## Technical data

**Model:** HORNFELS

**Type:** E2309-CN

250V ~ 50Hz 10A Max. 2500W



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for  recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.

# 繁中



請仔細閱讀說明書並妥善保存，以供參考。

## 重要事項！

- 請勿前後相互連接。
- 使用時請勿覆蓋產品。
- 請拔掉插頭以切斷電源。
- 只能在室內乾燥地方使用。

## 警告

- 如果發現受損，請丟棄產品。
- 使用時電線應盡可能展開，保留散熱空間，避免溫度上升熱量蓄積。
- 請避免產品超載。
- 切勿將其浸泡於水或其他液體中。
- 使用不當可能會損壞產品或危及人身或財產安全。
- 務必看顧孩子，確保他們不會將產品當作玩具。

## 保養說明

清潔前請先將插頭拔除，再用乾布擦拭產品。

## 使用須知

不使用時，請將延長線從電源插座拔下。

## 技術規格

型號：HORNFELS

類型：E2309-CN

250V ~ 50Hz 10A Max. 2500W



垃圾桶畫叉圖案表示產品不可當作家庭廢棄物丟棄。產品須依當地廢棄物規定丟棄處理。與家庭廢棄物分開擺放，可幫助減少送往焚化爐或掩埋場的廢棄物數量，並降低可能危害人體健康和環境的機會。請向IKEA客服部取得更多相關資訊。